# Minerals Management Service, Interior

casing, the casing shall be pressuretested, calipered, or otherwise evaluated every 30 days and the results submitted to the District Supervisor.

- (c) When the tree is installed, the wellhead shall be equipped so that all annuli can be monitored for sustained pressure. If sustained casing pressure is observed on a well, the lessee shall immediately notify the District Supervisor.
- (d) Wellhead, tree, and related equipment shall have a pressure rating greater than the shut-in tubing pressure and shall be designed, installed, used, maintained, and tested so as to achieve and maintain pressure control. New wells completed as flowing or gaslift wells shall be equipped with a minimum of one master valve and one surface safety valve, installed above the master valve, in the vertical run of the tree.
- (e) Subsurface safety equipment shall be installed, maintained, and tested in compliance with §250.801 of this part.

[53 FR 10690, Apr. 1, 1988, as amended at 55 FR 47753 Nov. 15, 1990. Redesignated and amended at 63 FR 29479, 29485, May 29, 1998]

# Subpart F--Oil and Gas Well-Workover Operations

### §250.600 General requirements.

Well-workover operations shall be conducted in a manner to protect against harm or damage to life (including fish and other aquatic life), property, natural resources of the Outer Continental Shelf (OCS) including any mineral deposits (in areas leased and not leased), the national security or defense, or the marine, coastal, or human environment.

#### § 250.601 Definitions.

When used in this subpart, the following terms shall have the meanings given below:

Routine operations mean any of the following operations conducted on a well with the tree installed:

- (a) Cutting paraffin:
- (b) Removing and setting pumpthrough-type tubing plugs, gas-lift valves, and subsurface safety valves which can be removed by wireline operations:

- (c) Bailing sand;
- (d) Pressure surveys;
- (e) Swabbing;
- (f) Scale or corrosion treatment;
- (g) Caliper and gauge surveys;
- (h) Corrosion inhibitor treatment:
- (i) Removing or replacing subsurface pumps;
- (j) Through-tubing logging (diagnostics);
- (k) Wireline fishing; and
- (1) Setting and retrieving other subsurface flow-control devices.

Workover operations mean the work conducted on wells after the initial completion for the purpose of maintaining or restoring the productivity of a well.

#### § 250.602 Equipment movement.

The movement of well-workover rigs and related equipment on and off a platform or from well to well on the same platform, including rigging up and rigging down, shall be conducted in a safe manner. All wells in the same well-bay which are capable of producing hydrocarbons shall be shut in below the surface with a pumpthrough-type tubing plug and at the surface with a closed master valve prior to moving well-workover rigs and related equipment unless otherwise approved by the District Supervisor. A closed surface-controlled subsurface safety valve of the pump-through-type may be used in lieu of the pumpthrough-type tubing plug provided that the surface control has been locked out of operation. The well to which a wellworkover rig or related equipment is to be moved shall also be equipped with a back-pressure valve prior to removing the tree and installing and testing the blowout-preventer (BOP) system. The well from which a well-workover rig or related equipment is to be moved shall also be equipped with a back pressure valve prior to removing the BOP system and installing the tree. Coiled tubing units, snubbing units, or wireline units may be moved onto a platform without shutting in wells.

## § 250.603 Emergency shutdown system.

When well-workover operations are conducted on a well with the tree removed, an emergency shutdown system (ESD) manually controlled station

#### § 250.604

shall be installed near the driller's console or well-servicing unit operator's work station, except when there is no other hydrocarbon-producing well or other hydrocarbon flow on the platform.

#### § 250.604 Hydrogen sulfide.

When a well-workover operation is conducted in zones known to contain hydrogen sulfide  $(H_2S)$  or in zones where the presence of H<sub>2</sub>S is unknown (as defined in §250.417 of this part), the lessee shall take appropriate precautions to protect life and property on the platform or rig, including but not limited to operations such as blowing the well down, dismantling wellhead equipment and flow lines, circulating the well, swabbing, and pulling tubing. pumps and packers. The lessee shall comply with the requirements in §250.417 of this part as well as the appropriate requirements of this subpart.

[53 FR 10690, Apr. 1, 1988. Redesignated and amended at 63 FR 29479, 29485, May 29, 1998; 64 FR 9065, Feb. 24, 1999]

#### § 250.605 Subsea workovers.

No subsea well-workover operation including routine operations shall be commenced until the lessee obtains written approval from the District Supervisor in accordance with §250.613 of this part. That approval shall be based upon a case-by-case determination that the proposed equipment and procedures will maintain adequate control of the well and permit continued safe production operations.

 $[53~{\rm FR}~10690,~{\rm Apr.}~1,~1988.~{\rm Redesignated}$  and amended at  $63~{\rm FR}~29479,~29485,~{\rm May}~29,~1998]$ 

## § 250.606 Crew instructions.

Prior to engaging in well-workover operations, crew members shall be instructed in the safety requirements of the operations to be performed, possible hazards to be encountered, and general safety considerations to protect personnel, equipment, and the environment. Date and time of safety meetings shall be recorded and available at the facility for review by a Minerals Management Service representative.

### §§ 250.607-250.608 [Reserved]

# § 250.609 Well-workover structures on fixed platforms.

Derricks, masts, substructures, and related equipment shall be selected, designed, installed, used, and maintained so as to be adequate for the potential loads and conditions of loading that may be encountered during the operations proposed. Prior to moving a well-workover rig or well-servicing equipment onto a platform, the lessee shall determine the structural capability of the platform to safely support the equipment and proposed operations, taking into consideration the corrosion protection, age of the platform, and previous stresses to the platform.

#### § 250.610 Diesel engine air intakes.

No later than May 31, 1989, diesel engine air intakes shall be equipped with a device to shut down the diesel engine in the event of runaway. Diesel engines which are continuously attended shall be equipped with either remote operated manual or automatic shutdown devices. Diesel engines which are not continuously attended shall be equipped with automatic shutdown devices.

[53 FR 10690, Apr. 1, 1988, as amended at 54 FR 50616, Dec. 8, 1989. Redesignated at 63 FR 29479, May 29, 1998]

# § 250.611 Traveling-block safety device.

After May 31, 1989, all units being used for well-workover operations which have both a traveling block and a crown block shall be equipped with a safety device which is designed to prevent the traveling block from striking the crown block. The device shall be checked for proper operation weekly and after each drill-line slipping operation. The results of the operational check shall be entered in the operations log.

## § 250.612 Field well-workover rules.

When geological and engineering information available in a field enables the District Supervisor to determine specific operating requirements, field well-workover rules may be established on the District Supervisor's initiative